

JBCNC I/O-kort port 2

Jumper: Sourcing 5v

1 ⊖

Jumper: Sourcing 5v

2 ⊖

<Inbyggt forkopplingsmotstand>

EPS-B2-0D40AA Servo X

DB15 Break out board

⊖ 2 PULS+

⊖ 4 DIR+

JBCNC I/O-kort port 3

Sinking outputs

9 ⊖

14 ⊖

16 ⊖

17 ⊖

0VDC ⊖

24VDC ⊖

⊖ 10 DI1 (Enable)

⊖ 11 DI2 (Alarm reset)

⊖ 3 PULS-

⊖ 5 DIR-

⊖ 14 COM+

JB CNC & Linear Components

Servostyrning EPSB1-B2

JB

Rev 1.0

2019-08-07